ADVANCED THREAD TIGHTENING ROBOT **NITOMAN RC5500-S**THREAD TIGHTENING ROBOT CONTROLLER

USER'S MANUAL Ver 1.02



NITTO SEIKO CO.,LTD.

[Notes]

- (1) All rights reserved. No part of or whole of this may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without the prior written permission of Nitto Seiko Co., Ltd.
- (2) By provision of operating manual recorded on CD-ROM, you shall be deemed to have agreed to the Terms and Conditions written in "readme.txt" on it.
- (3) Contents of this manual are subject to update without notice according to specification change of the products.
- (4) Unique nouns like the product name indicated in this brochure are registered or not registered trademark of each company.

Safety precautions

Before using this machine, fully read the safety precautions shown below for correct use.

- ◆ To secure safety of the robot, refer to JIS B 8433-1993 (Safety of industrial manipulating robot).
- ◆ This machine is designed and manufactured for the purpose of use for general industrial machinery.
- ◆ Installation of the robot and setup of the system must be carried out by technicians only.
- ♦ When moving or selling this machine, have the owner to be fully read this manual for correct use.

To prevent hazards to operators or other persons and damages to properties, be sure to observe the instructions in this operation manual shown below.

Marks indicating possible hazards and damages

| \triangle | WARNING | Noncompliance with the instructions adjacent to this mark may lead to a loss of life or serious injury. |
|-------------|---------|---|
| <u> </u> | CAUTION | Noncompliance with the instructions adjacent to this mark may lead to injury or physical damages. |

Marks showing points to be observed

| 0 | This mark is accompanied with acts to be prohibited. |
|---|--|
| 0 | This mark is accompanied with acts to be performed. |

∕!\ WARNING

[Installation]

Be sure to provide grounding cables.



Otherwise, you may suffer electric shocks.

DO NOT use this machine near combustibles, inflammables, and explosive substances, or in the corrosive or flammable atmosphere.



Otherwise, combustion, inflammation, or explosion may occur.

DO NOT use this machine where the robot and the controller may be splashed with water or oil.



Otherwise, malfunctions, fires, or electric shocks may occur.

DO NOT modify the robot and the controller. NEVER connect the controller to the robot other than of the specified type.



Otherwise, the controller may be damaged, or the robot may be malfunctioned, causing fires or serious accidents.

DO NOT install the robot and the controller to the locations where are unstable or subjected to vibrations.



Otherwise, the robot may be moved or tipped, leading to accidents or breakage.

Install the safety guard to the outside of motion areas.



Otherwise, you may suffer serious injury. For safety, be sure to provide the interlock switch for the door of the safety guard. Secure working space to carry out works related to teaching, maintenance, and check safely.

∕ WARNING

[Installation]

DO NOT damage cables.



NEVER damage, forcibly bend or pull, wind, pinch them, nor put heavy objects on them. Otherwise, fires, electric shocks, or malfunctions due to earth leakage or disconnection may be caused.

Correctly carry out wiring, referring to "Operation Manual".



Be sure to connect cables and connectors securely to prevent any looseness or disconnection. Otherwise, malfunctions or fires may occur.

Always provide the emergency stop switch for a location convenient for operation.



Otherwise, you cannot deal with unexpected troubles quickly, causing serious injury.

! WARNING

[Operation]

When you find any heating, fume, or odor, immediately turn off the power switch, and disconnect the power plug.



Otherwise, the machine may be damaged, or fires may occur.

Make sure that the machine is in the "SERVO OFF" mode (operated by the teaching pendant) before operating the moving parts of the robot by the direct teaching.



Otherwise, you may suffer injury.

NEVER use the robot or the controller if they have been dropped or immersed in water.



Otherwise, malfunctions or electric shocks due to faults or damages may occur.

[Maintenance and check]

Turn off the power switch, disconnect the power plug to shut off the power completely, and wait for ten minutes or longer before moving, wiring, or checks. Wiring must be provided by electrical technicians only.



Provision of these measures helps prevention of electric shocks.

Be sure to read operation manual before maintenance and check.



Otherwise, accidents may occur in case of misoperation.

⚠ CAUTION

[Installation]

Completely provide electric shielding measures before using this machine in the locations shown below. Otherwise, malfunctions may occur.



- 1. Where there are high tension current or great magnetic field
- 2. Where welding is being performed and arc discharge may occur
- 3. Where noises due to static electricity are generated
- 4. Where exposure to radio activity may occur

DO NOT hold moving parts or cables when installing the machine.



Otherwise, you may suffer injuries.

NEVER block the vent of the controller.



Otherwise, heat is trapped in the machine, leading to fires or malfunctions.

DO NOT use this machine outdoors exposed to direct sunlight.



Otherwise, malfunctions or faults may occur.

[Operation]

Be sure to use this machine in locations where ambient temperature is within the range between 0°C and 40°C, humidity is within the range between 30% and 80%, free from dew condensation.



Otherwise, malfunctions, fires, or electric shocks may occur.

DO NOT use this machine with the power supply and under the voltage other than specified.



Otherwise, malfunctions, fires, or electric shocks may occur.

Table of contents

| 1. | Pref | ace | 8 |
|----|---------|---|----|
| | 1.1 | Outline of system | 8 |
| | 1.2 | Product structure | 9 |
| 2. | Insta | allation | 10 |
| | 2.1 | Names and functions of components | 10 |
| | 2.2 | Specifications | 15 |
| | 2.2. | 1 Specifications of robot controller | 15 |
| | 2.2.2 | 2 Specifications of external I/O | 16 |
| | 2.3 | System setup | 19 |
| | 2.3. | Connecting robot controller RC5500-S with robot | 19 |
| | 2.3.2 | 2 I/O connection diagram | 21 |
| | 2.3.3 | 3 Interface list | 25 |
| | 2.3.4 | 4 Connector pins assignment | 27 |
| | 2.3.5 | 5 Outside dimensions | 32 |
| | 2.3.0 | 6 Robot controller inside parts location | 33 |
| | 2.3. | 7 PI-50-01 Layout of terminal block on PCB | 35 |
| | 2.3.8 | 8 CN-50-01 PCB short-circuit pin | 37 |
| | 2.4 | Maintenance and inspection | 39 |
| 3. | App | endix | 40 |
| | 3.1 | Replacing battery | 40 |
| | 3.2 | Encoder reset (initialization) procedure | 45 |
| | 3.3 | Origin setup | 50 |
| | 3.4 | Releasing holding brake | 56 |
| | 3.5 | Robot coordinate system | 60 |
| | 3.6 | Ready circuit | 61 |
| | 3.7 | Precautions | 62 |
| | 3.8 | Guarantee period and coverage | 63 |
| | [Revisi | ion record] | 64 |
| | May 20 | 010, first edition, RC5500-S Ver 1.00 RC5500-S0001 | 64 |
| | Dec 20 | 016, Revision edition, RC5500-S Ver 1.01 RC5500-S0002 | 64 |
| | Feb 20 | 118, Revision edition, RC5500-S Ver 1.02 RC5500-S0003 | 64 |

1. Preface

Thank you for your purchase of our product.

Fully read this manual for correct use.

After reading it, keep it for later reference by users. Be sure to hand it to the end user.

1.1 Outline of system

Advanced Thread Tightening Robot $SR565Y\theta$ aims to improve the functions of our conventional model $SR560Y\theta$, based on the basic system configuration equivalent to that of the conventional model. The teaching pendant is equipped with a handy type 5.7-inch color LCD touch panel. It provides high operability, and incorporates a teaching ON/OFF key switch and a 3-position (OFF-ON-OFF) deadman switch in consideration of safety. The teaching pendant, also used as the control panel for the thread tightening robot, features superior cost performance.

This system allows storage of information on the position of the robot into the three tables, "Thread tightening point", "Fixed point", and "Palletizing point".

At the thread tightening point, teaching and record of the thread tightening position are performed. Up to forty points for each of a hundred types of models from 0 to 99 can be recorded. Furthermore, at this point, two sets of work information per point can be stored, and selection of screw parameter ($SR565Y\theta$ -Z only), setup of thread tightening, and setup of tightening torque channel are possible.

At the "Fixed point", up to forty fixed points that do not depend on the types of works, such as standby positions, can be recorded.

At the "Palletizing point", three groups of up to two hundred of points can be recorded.

(Note: The "Palletizing point" is not applicable to the "Y θ " type robot.)

Machine controller is used as the main control unit of the robot controller, and the thread tightening robot control software enables various types of control functions required for thread tightening.

The difference between this model and the conventional controller RC5500-S is shown below. The robot controller operating procedure is the same as that for the conventional model, enabling you to use this model without confusion.

1. Specifications of controller

| Model of controller | RC5500-S | RC5000-S |
|--|--|---|
| Number of control axes | 6 axes max. | 4 axes max. |
| Serial port | RS232C (for teaching pendant.) | RS232C: 2 ports |
| | Ethernet (100BASE-TX) (for PC connection) | (Including one port for teaching pendant) |
| External input | Standard user port: 16 ports | Standard user port: 4 ports (For Z-type: 7 |
| | [External 64 ports can be added.] | ports) |
| | | [Internal 16 ports and external 64 ports can be |
| | | added.] |
| External output | Standard user port: 16 ports | Standard user port: 4 ports (For Z-type: 7 |
| | [External 64 ports can be added.] | ports) |
| | | [Internal 16 ports and external 64 ports can be |
| | | added.] |
| Field network | CC-Link slave interface | None |
| Point control | Work area: 40 (50 *1) points × 100 types | Work area: 40 points × 100 types |
| | Fixed area: 40 (50 *1) points | Fixed area: 40 points |
| | Palletizing area: 200 points × 3 groups | Palletizing area: 200 points × 3 groups |
| | (Palletizing function is not applicable to the | (Palletizing function is not applicable to the |
| | Yθ-type robot.) | Yθ-type robot.) |
| Point work information | 2 sets per point (4 sets *1) | 2 sets per point |
| | (Operation pattern, torque) | (Operation pattern, torque) |
| Sequence program | Ladder diagram (equivalence to 40K steps) | Ladder diagram (equivalence to 8K steps) |
| Outside dimensions (W \times H \times D) | 200 (250 *1) × 450 × 420 mm | $200\times450\times470~\text{mm}$ |
| , , , , , , , , , , , , , , , , , , , | (Excluding rubber feet) | (Excluding rubber feet) |
| | | *1. Depending on enceifications |

^{*1:} Depending on specifications.

^[] is optionally available.

1. Preface

2. Applicable equipment

| | RC5500 | RC5000 | |
|------------------|-----------|------------|-----------------------------|
| CPU | MP2310 | MP930 | (Yaskawa Electric Corp.) |
| Servo motor | ΣV series | ΣII series | (Yaskawa Electric Corp.) |
| Servo amplifier | ΣV series | ΣII series | (Yaskawa Electric Corp.) |
| Teaching pendant | GT1455HS | F940GOT | (Mitsubishi Electric Corp.) |

1.2 Product structure

Our model number of the thread tightening robot controller should be indicated as shown below.

Model RC5500-S Ver.*.**

Accessories

Power supply cable, 3 m (CN51CBO) 1 pce.

Servo power cable, 3 m (CN52-CBO3A) 1 pce.

Encoder cable, 3 m (CN53-CBO3A) 1 pce.

Feeder power supply/control cable 3 m (CN54-CBO) 1 pce.

Driver power supply cable 3 m (CN56-CBO) 1 pce.

Driver control cable 3 m (CN57-CBO) 1 pce.

Standard I/O (1 A) cable 3 m (CN58-CBOA) [for biaxial type only] 1 pce.

Teaching pendant RC5500TS (GT1455HS-QTBDE, Mitsubishi Electric Corp.) 1 unit

Teaching pendant connector cable, 3 m (GT11H-C30-37P, Mitsubishi Electric Corp.) 1 pce.

One complete set of the items shown above is provided for our standard type machine (for SR565Yθ single unit).

Optional items

Standard I/O (1 A) cable, 3 m (CN58-CBOA) [for types other than biaxial type]

Standard I/O (1B) cable, 3 m (CN58-CBOB)

Standard I/O (2) cable, 3 m (CN59-CBO)

CC-Link slave interface

External add-on I/O unit

Teaching pendant connection cable 6 m (GT11H-C60-37P, Mitsubishi Electric Corp.)

Protective sheet (GT14H-50PSC, Mitsubishi Electric Corp.)5 sheets per set

• Specify the models of optional items when purchasing them.

Related manual

Advanced thread tightening robot, nitoman RC5500TS Teaching Pendant, Operation Manual

2. Installation

2.1 Names and functions of components

1) Front of robot controller

[1] Power switch

When the "I" side of the robot controller power switch is pressed, power is supplied. When the "O" side is pressed, power is shut off.

[2] CNPC (PC connector)

This Ethernet connector connects the robot controller and the PC. [Controller side model: NWMJ-C5E-DCTR-WH (MISUMI)]

[3] RUN lamp (Green)

This lamp lights up when power is supplied to the robot controller, power switch [1] is turned on, and the CPU is correctly operated.

[4] ALARM lamp (Red)

This lamp lights up when the robot system is faulty.


[5] CNTP (Teaching pendant connector)

This connector connects the robot controller and the teaching pendant.

When the teaching pendant is not connected, the robot must be connected to the optional short-circuit receptacle. (The robot enters the emergency stop status unless it is connected to the short-circuit receptacle.) [Controller side model: XM2D-3701 (OMRON)]

[6] Product nameplate

This product nameplate is attached to the robot controller.



2) Back of robot controller

[1] CN52A (Servo power supply connector "A" side)

This connector is used for servo motor output. For control of a single thread tightening robot, only "A" side should be connected. Three or four motor axes can be controlled.

[Controller side model: D/MS3102A22-14S (DDK)]

[2] CN53A (Encoder connector "A" side)


This connector is used for encoder input. For control of a single thread tightening robot, only "A" side should be connected. Three or four motor axes can be controlled.

[Controller side model: XM2D-2501 (OMRON)]

[3] CN52B (Servo power supply connector "B" side)

This connector is used for servo motor output. For control of two thread tightening robots, the "B" side should be also connected. Up to three motor axes can be controlled. For use of the "A" side only, a panel plug is attached.

[Controller side model: D/MS3102A22-14S (DDK)]



[4] CN53B (Encoder connector "B" side)

This connector is used for encoder input. For control of two thread tightening robots, the "B" side should be also connected. Up to three motor axes can be controlled. For use of the "A" side only, a panel plug is attached. [Controller side model: XM2D-2501 (OMRON)]

[5] FAN0 (Cooling fan)

This suction type fan is used for cooling in the controller. Clogs in the fan filter may lead to insufficient cooling. Periodically clean the filter.

[Fan model: MD925A-24 (Oriental Motor)], [Filter model: FL9 (Oriental Motor)]

[6] Grommet with coating (for wiring)

The grommet is used to pass the I/O signal cable from the robot controller to outside. Two pieces are supplied with the controller. However, they may have been already used before shipment, depending on the type of the thread tightening robot.

[Type of grommet: C-30-SG-22A (TAKIGEN)]

[7] CN59 (Standard I/O-2 connector)

A connector for the standard I/O-2 (IB110-11F and OB110-11F) input and output signals. In addition to the I/O signals, external emergency stop input, and external emergency stop output are also assigned to the connector. With the CN59 connector, you can select "enable or disable" status of 24 VDC output to external equipment by using the short-circuit pins (SP1 and SP2) on the CN-50-01 PCB. With the standard setting, the 24 VDC external output is disabled. However, if "output" is to be enabled depending on specifications, the 24 VDC power supply for I/O is output via this connector. Be careful not to short-circuit the connector during wiring. [Controller side model: XM8F-5022-12 (OMRON)]

[8] CN58B (Standard I/O-1B connector)

A connector for the standard I/O-1B (IB10D-114 and OB10D-114) input and output signals. The 24 VDC power supply for I/O is output via this connector. Be careful not to short-circuit the connector during wiring. [Controller side model: XM8F-2422-12 (OMRON)]

[9] CN58A (Standard I/O-1B connector)

A connector for the standard I/O-1B (IB105-10C and OB105-10C) input and output signals. The 24 VDC power supply for I/O is output via this connector. Be careful not to short-circuit the connector during wiring. [Controller side model: XM8F-2422-12 (OMRON)]

[10] TB0 (External emergency stop, external start signal input terminal block)

This terminal block is intended for input of external emergency stop and external start signals.

To input the external emergency stop signal, input from the b-contact between the two terminals in the upper side of the terminal block. When no external emergency stop signal is used, short-circuit the terminals. Otherwise, the robot enters the emergency stop status. To input the external start signal, connect between the two terminals in the lower side of the terminal block. (For details of connection, refer to "2.2.2 Specifications of external I/O".)

[11] CN57A (Driver control connector "A" side)

A connector for the control signal dedicated to the first thread tightening driver controller SD5**(T). The 24 VDC power supply for I/O

is output via this connector. Be careful not to short-circuit the connector during wiring. [Controller side model: XM8L-2423 (OMRON)]

[12] CN56A (Driver power supply connector "A" side)

A connector for the power supply dedicated to the first thread tightening driver controller SD5**(T). Be careful to handle this connector, because power supply voltage is output from this connector after the ready switch is turned ON.

[Controller side model: NJC-20-3-RF (UL) (Nanaboshi)]

[13] CN55A (Feeder control connector "A" side)

A connector for the control signal dedicated to the first screw feeder FF***H. [Controller side model: XM8L-1423 (OMRON)]

[14] CN54A (Feeder power supply connector "A" side)

A connector for the power supply dedicated to the first screw feeder FF***H. Be careful to handle this connector, because power supply voltage is output from this connector after the ready switch is turned ON. [Controller side model: NJC-20-3-RF (UL) (Nanaboshi)]

[15] CN57B (Driver control connector "B" side)


A connector for the control signal dedicated to the second thread tightening driver controller SD5**(T). The 24 VDC power supply for I/O is output via this connector. Be careful not to short-circuit the connector during wiring. For use of the "A" side only, a panel plug is attached.

[Controller side model: XM8L-2423 (OMRON)]

[16] CN56B (Driver power supply connector "B" side)

A connector for the power supply dedicated to the second thread tightening driver controller $SD5^{**}(T)$. Be careful to handle this connector, because power supply voltage is output from this connector after the ready switch is turned ON. For use of the "A" side only, a panel plug is attached.

[Controller side model: NJC-20-3-RF (UL) (Nanaboshi)]



[17] CN55B (Feeder control connector "B" side)

A connector for the control signal dedicated to the second screw feeder FF***H. For use of the "A" side only, a panel plug is attached.

[Controller side model: XM8L-1423 (OMRON)]

[18] CN54B (Feeder power supply connector "B" side)

A connector for the power supply dedicated to the second screw feeder FF***H. Be careful to handle this connector, because power supply voltage is output from this connector after the ready switch is turned ON. For use of the "A" side only, a panel plug is attached.

[Controller side model: NJC-20-3-RF (UL) (Nanaboshi)]

[19] CN51 (Power supply connector)

A connector for the controller main power supply. Applicable power supply voltage is 200 V to 230 VAC. Do not use this connector for other than the specified power supply voltage. Be sure to ground the green/yellow earth cable for protection against electric shock.

[Controller side model: NJC-24-3-RM (UL) (Nanaboshi)]

[Type of power supply connector: WF4315 (Matsushita Electric Works, Ltd.)]

3) Teaching pendant

[1] Ready button

When this button is pressed while power is supplied to the robot controller, the CPU works correctly, and emergency status is completely reset (short-circuited), the ready lamp [3] lights up, power is supplied to the servo motor, power of 24 VDC is supplied to between the P and N of the I/O signal power supply, and the machine is ready for operation.


[2] POWER lamp

This lamp lights up while power is supplied to the robot controller.

[3] Liquid crystal display with touch switches This 65536 color displayer comprises liquid crystal elements with the touch switches.

[4] TEACH OFF/ON key switch

Teaching valid/invalid status can be switched with this switch. Set this switch to the left side, "TEACH OFF" position, during the normal



operation. In this status, the key can be removed. When carrying out teaching or any setup, insert the key, and set it to the right side, "TEACH ON" position. In this status, neither automatic running nor removal of the key is possible.

[5] Main unit hanging bracket

A bracket to hang the robot body.

[6] Emergency stop switch

This is the push-lock and turn-reset type emergency stop switch. When it is pressed, it is locked with pushed-in, and the robot enters the emergency stop status. To cancel the emergency stop status, turn the button into the arrow direction (clockwise).

[7] Deadman switch lamp

This lamp lights up when the deadman switch on the side is turned on.

[8] Deadman switch

This is the three-position type deadman switch. When you release your finger from this switch, it is turned off. When you press it in once, it is turned on. When you press it in again, it is turned off. When performing teaching or the JOG operation of axes, or moving to your intended points that teaching has already been completed, this switch must be pressed in once to turn it on.

(For operating procedures of the teaching pendant, refer to the separate "Operation Manual for Advanced Thread Tightening Robot nitoman RC5500TS Teaching Pendant".)

2.2 Specifications

2.2.1 Specifications of robot controller

Thread tightening robot controller RC5500-S

| Items | Model: RC5500-S | | | |
|---------------------------------|---|--|--|--|
| Power supply voltage | Single phase, from 200 VAC to 230 VAC, 50/60 Hz | | | |
| Number of axes to be controlled | Maximally six | | | |
| Positioning system | PTP, linear, circular, and helical interpolation (interpolation is inapplicable to Yθ-type robots) | | | |
| Position detecting system | Absolute value encoder system (battery backup "ER6VC4": approximately 5 years) | | | |
| Serial port | RS232C: Used for the teaching pendant. Ethernet (100Base-TX/10Base-T): For PC connection | | | |
| Memory | RAM (battery backup "JZSP-BA01": approximately 5 years) | | | |
| External input | Standard user port, 16-pos. (For a single thread tightening robot) Up to 64 external ports can be added. | | | |
| External output | Standard user port, 16-pos. (For a single thread tightening robot) Up to 64 external ports can be added. | | | |
| Field network | CC-Link slave interface | | | |
| Teaching system | MDI, remote teaching, direct teaching | | | |
| Point control | Work area: 40 (50 *1) points x 100 models Fixed area: 40 points (50 *1) Palletize area: 200 points \times 3 patterns (inapplicable to Y θ -robots) | | | |
| Point work information | 2-sets per point (4-sets *1): Torque/operation pattern selection | | | |
| Sequence program | Ladder diagram (40K step or equivalence) | | | |
| Robot program | Special motion language | | | |
| Outside dimensions (WxHxD) | 200 (250 *1) × 450 × 470 | | | |
| Weight | Approximately 20 kg | | | |
| Teaching pendant | Handy type touch panel (with key switch and deadman switch) Teaching pendant can be used as control panel | | | |
| PC software | Provided (optional) | | | |


^{*1:} Depending on specifications

2.2.2 Specifications of external I/O

1) General purpose signal input unit

| Items | Specifications | | | | | |
|------------------------|--|---|--|--|--|--|
| Number of input points | Standard user port: Internal 16 ports (For a single thread tightening robot) | Expansion user port: External 64 ports (Optional) | | | | |
| Input voltage | 24 VDC ±20% (+19.2 to +28.8 V) | 24 VDC (+20.4 to +28.8 V) | | | | |
| Input current | 4.1 mA/input | 5.0 mA/input | | | | |
| Response time | From OFF to ON: 0.5 ms max. From ON to OFF: 0.5 ms max. | From OFF to ON: 2 ms max. From ON to OFF: 3 ms max. | | | | |
| Input type | Sink input | | | | | |
| Insulation system | Photocoupler | | | | | |

Internal circuit configuration



- *1: CR01 is the operation ready relay (When the machine is ready for operation, the CR01 is tripped.)
- *2: With the CN59 connector, you can select "enable" or "disable" status of internal 24 VDC (R-P, R-P0) output to external equipment, depending on the setting of the short-circuit pins (SP1 and SP2) on the CN-50-01 PCB.






From the R-P0 and R-P terminals of the external I/O connector, +24 V power in the robot controller is output.

DO NOT provide external power supply to the R-P0 and R-P terminals.

2) General purpose signal output unit

| Items | Specifications | | | | | |
|-------------------------|--|---|--|--|--|--|
| Number of output points | Standard user port: Internal 16 ports (For a single thread tightening robot) | Expansion user port: External 64 ports (Optional) | | | | |
| Rated load voltage | 24 VDC ±20% (+19.2 to +28.8 V) | 24 VDC (+20.4 to +28.8 V) | | | | |
| Max. load current | 100 mA/input | 50 mA/input | | | | |
| Leak current at OFF | 0.1 mA max. | | | | | |
| Response time | From OFF to ON: 0.5 ms max. From ON to OFF: 0.5 ms max. | From OFF to ON: 2 ms max. From ON to OFF: 3 ms max. | | | | |
| Output type | Transistor/sink output | | | | | |
| Insulation system | Photocoupler | | | | | |

Internal circuit configuration



- *1: CR01 is the operation ready relay (When the machine is ready for operation, the CR01 is tripped.)
- *2: With the CN59 connector, you can select "enable" or "disable" status of internal 24 VDC (R-P, R-P0) output to external equipment, depending on the setting of the short-circuit pins (SP1 and SP2) on the CN-50-01 PCB.


⚠ CAUTION



From the R-P0 and R-P terminals of the external I/O connector, +24 V power in the robot controller is output.

DO NOT provide external power supply to the R-P0 and R-P terminals.

3) External signal connection terminal block TB0




^{*} EM1 and EM2 are also connected in parallel with CN59.

2.3 System setup


2.3.1 Connecting robot controller RC5500-S with robot

1) General connection drawing of thread tightening robot



* The above figure shows connections of $SR565Y\theta$ (-Z). When two thread tightening robots are used, one set of the thread tightening robot main unit, screw feeder, thread tightening driver controller should be added each.


2) Drawing of connection on the back of controller



* The above figure shows connections of $SR565Y\theta$ (-Z). When two thread tightening robots are used, one set of the thread tightening robot main unit, screw feeder, thread tightening driver controller should be added each.


2.3.2 I/O connection diagram

1) Standard I/O (For a single SR565Y θ thread tightening robot)



- *1: Input from IB105 to 10C and output from OB105 to 10C can be taken out from the connector CN58A on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.
- *2: Input from IB10D to 114 and output from OB10D to 114 can be taken out from the connector CN58B on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.
- *3: Input from IB110 to 11F and output from OB110 to 11F can be taken out from the connector CN59 on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.

2) Standard I/O (For double SR565Y θ thread tightening robots)



- *1: Input from IB105 to 10C and output from OB105 to 10C can be taken out from the connector CN58A on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.
- *2: Input from IB10D to 114 and output from OB10D to 114 can be taken out from the connector CN58B on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.
- *3: Input from IB110 to 11F and output from OB110 to 11F can be taken out from the connector CN59 on the back of the RC5500-S or the terminal block on the PCB PI-50-01 in the RC5500-S.

3) Controller external expansion I/O-1 (Optional: Remote I/O unit can be externally added to the controller)

| NO PO (R-NO)(R-PO) | | | | | (R- | , ОИ) | (P- | 0 P() |
|-----------------------|---------|---------|---------|--------|----------|----------|-----|----------|
| | I 0,231 | . 0 | I | 26310 | | | (1) | 1 0) |
| | +24V_2 | B 2 | A 1 | 024V_6 | | ļ | | |
| | +24V_2 | A 2 | B 1 | 024V_6 | | ļ | | |
| | +24V_1 | B 20 | B 19 | 024V_5 | | ļ | | |
| | +24V_1 | A 20 | A 19 | 024V_5 | | 1 | | |
| | | | A 2 | +24V_6 | <u> </u> | | | |
| | | | B 2 | +24V_6 | | | | |
| | | | B 20 | +24V_5 | | | - | |
| | | | A 20 | +24V_5 | | | | |
| | IB120 | B 18 | B 18 | OB220 | OB220 | | | |
| | IB121 | A 18 | | OB221 | OB221 | | | |
| | IB122 | B 17 | | OB222 | OB222 | | - | |
| | IB123 | A 17 | | OB223 | OB223 | | | |
| | IB124 | | B 16 | OB224 | OB224 | | | , |
| IB126 | IB125 | A 16 | | OB225 | OB225 | | - | |
| IB126 | IB126 | B 15 | B 15 | OB226 | OB226 | | _ | , |
| IB127 | IB127 | A 15 | | OB227 | OB227 | | | . ——— |
| IB128 | IB128 | B 14 | B 14 | OB228 | OB228 | | | |
| IB129 | IB129 | A 14 | A 14 | OB229 | OB229 | | | |
| | IB12A | B 13 | | OB22A | OB22A | | | |
| | IB12B | A 13 | | OB22B | OB22B | | | |
| | IB12C | B 12 | | OB22C | OB22C | | | |
| | IB12D | A 12 | | OB22D | OB22D | | | |
| | IB12E | B 11 | B 11 | OB22E | OB22E | | | |
| IB12E | IB12F | A 11 | | OB22F | OB22F | | | |
| | | | | | 1 | | | |
| | IB130 | B 10 | B 10 | OB230 | OB230 | | | |
| | IB131 | A 10 | A 10 | OB231 | OB231 | | | |
| | IB132 | B 9 | B | OB232 | OB232 | | | |
| | IB133 | A g | A 9 | OB233 | OB233 | | | |
| | IB134 | B 8 | B 8 | OB234 | OB234 | | - | |
| IB136 | IB135 | A 8 | A 8 | OB235 | OB235 | | _ | , |
| IB136 | IB136 | B 7 | B 7 | OB236 | OB236 | | | |
| IB137 | IB137 | A 7 | A 7 | OB237 | OB237 | | | |
| | IB138 | B 6 | B 6 | OB238 | OB238 | | - | |
| IB139 | IB139 | A 6 | | OB239 | OB239 | | | |
| IB13A | | B 5 | B 5 | OB23A | OB23A | | - | |
| IB13E | | A 5 | A 5 | OB23B | 0В23В | | _ | , |
| IB130 | | B 4 | B 4 | OB23C | OB23C | | | |
| IB13E | | A 4 | A 4 | OB23D | OB23D | | | |
| | | B 3 | B 3 | OB23E | OB23E | | | |
| | | A 3 | A 3 | OB23F | OB23F | | | |
| NIO. | | , , | | | 4 | | ם. | \cap |
| (R-NO) | | | | | | | (R- | ŘΟ) |

^{*} Located in the controller external expansion box.

4) Controller external expansion I/O-2 (Optional: Remote I/O unit can be externally added to the controller)

| NO PO (R-NO)(R-PO) | | | | NO (R-NO) | PO |
|-----------------------|-----------|-------------|----------|--|---------------|
| (R-NO)(R-PO) | I 0,2,3,1 | 0 1 | 82310 | | (K-PO) |
| | +24V_2 | B # | A 024V_6 | - | |
| | +24V_2 | A E | 3 0247 6 | | |
| | +24V_1 | B E 20 1 | 3 024V_5 | | |
| | +24V_1 | A A 20 1 | A 024V_5 | | |
| | | 1 2 | | | |
| | | E | +24V_6 | | |
| | | E | 0 7247_5 | | |
| | | A | | | |
| | IB140 | B E 18 1 | | OB240 | |
| | IB141 | A A 18 1 | | OB241 | |
| | IB142 | B E 17 1 | | OB242 | |
| | IB143 | A A 17 1 | | OB243 | |
| | IB144 | B E | | OB244 | |
| | IB145 | A A | | OB245 | |
| | IB146 | B E | 5 00240 | OB246 | |
| | IB147 | A A | | OB247 | |
| | IB148 | B E | 4 00240 | OB248 | |
| | IB149 | A A 1 | | OB249 | |
| | IB14A | B E | | OB24A | |
| | IB14B | A A | 3 00240 | OB24B | |
| IB14C | IB14C | B 12 1 | 2 00240 | OB24C | |
| | IB14D | A A | | OB24D | |
| IB14E | IB14E | B E | 1 00245 | OB24E | |
| IB14F | IB14F | A / | OB24F | OB24F | |
| IB150 | | D 1 | | OB250_ | |
| | IB150 | B E | | OB251 | |
| | IB151 | A A 10 1 | | OB252 | |
| | IB152 | B E | | OB253 | |
| | IB153 | A A 9 9 | | OB254 | |
| | IB154 | B B 8 | | OB255 | |
| | IB155 | A A 8 | | OB256 | |
| IB157 | IB156 | B E 7 7 | | OB257 | |
| IB158 | IB157 | A 7 7 7 B B | | OB258 | |
| IB159 | IB158 | 6 6 | 5 00200 | OB259 | |
| | IB159 | A A 6 | | OB25A | |
| IB15B | IB15A | B E 5 | | OB25B | |
| IB16C | IB15B | A A 5 5 | | OB25C | |
| IB15D | IB15C | B E 4 | | OB25D | |
| IB16E | IB15D | A A A B B B | | OB25E | |
| IB15F | IB15E | B B B 3 | | OB25F | |
| | IB15F | A A | OB25F | | |
| N'O (R-NO) | | | | | P'O (R-PO) |
| (12 110 / | | | | | / |

^{*} Located in the controller external expansion box.

2.3.3 Interface list

1) Standard I/O connectors CN58A, CN58B connection list (Cable is optional for types other than cylinder type)

[CN58A]

23

24 Hood Ν

SG

CN58A CN58A Connection Cable Signal Pin No. cable No 24 VDC+ P0 Orange (1 point, red) N0 Gray (1 point, red) 24 VDC GND IB105 White (1 point, red) Input 4 IB107 Yellow (1 point, red) Input 5 IB109 Pink (1 point, red) Input IB10B 6 Orange (2 point, red) Input OB105 Gray (2 point, red) Output 8 **OB107** White (2 point, red) Output 9 OB109 Yellow (2 point, red) Output OB10B Pink (2 point, red) Output 11 Orange (3 point, red) 12 Ρ Gray (3 point, black) 24 VDC+ 13 P0 24 VDC+ Orange (1 point, black 24 VDC GND 14 N0 Gray (1 point, black) 15 IB106 White (1 point, black) Input Yellow (1 point, black) IB108 Input 16 17 IB10A Pink (1 point, black) Input 18 IB10C Orange (2 point, black) Input Gray (2 point, black) 19 **OB106** Output 20 OB108 White (2 point, black) Output 21 OB10A Yellow (2 point, black) Output 22 OB10C Pink (2 point, black) Output

[CN58B]

| CN58B Pin No. | CN58B Connection cable No. | Cable | Signal |
|------------------|----------------------------------|-------------------------|------------|
| 1 | P0 | Orange (1 point, red) | 24 VDC+ |
| 2 | N0 | Gray (1 point, red) | 24 VDC GND |
| 3 | IB10D | White (1 point, red) | Input |
| 4 | IB10F | Yellow (1 point, red) | Input |
| 5 | IB111 | Pink (1 point, red) | Input |
| 6 | IB113 | Orange (2 point, red) | Input |
| 7 | OB10D | Gray (2 point, red) | Output |
| 8 | OB10F | White (2 point, red) | Output |
| 9 | OB111 | Yellow (2 point, red) | Output |
| 10 | OB113 | Pink (2 point, red) | Output |
| 11 | - | Orange (3 point, red) | - |
| 12 P | | Gray (3 point, black) | 24 VDC+ |
| 13 | P0 | Orange (1 point, black) | 24 VDC+ |
| 14 | N0 | Gray (1 point, black) | 24 VDC GND |
| 15 | IB10E | White (1 point, black) | Input |
| 16 | IB110 | Yellow (1 point, black) | Input |
| 17 | IB112 | Pink (1 point, black) | Input |
| 18 | IB114 | Orange (2 point, black) | Input |
| 19 | OB10E | Gray (2 point, black) | Output |
| 20 | OB110 | White (2 point, black) | Output |
| 21 | OB112 | Yellow (2 point, black) | Output |
| 22 | OB114 | Pink (2 point, black) | Output |
| 23 | - | Orange (3 point, black) | - |
| 24 | N | Gray (3 point, black) | 24 VDC GND |
| Hood | SG | Shield | Shield |

CN58A, CN58B Connector model XM8A-2421 (OMRON)

Orange (3 point, black)

Shield

Gray (3 point, black)

2) Standard I/O-2 connector CN59 connection list (Both of connector and cable are optional)

24 VDC GND

Shield

| CN59 | Wire | 0.11 | 0 | |
|---------|-------|-----------------------|-----------------------------|--|
| Pin No. | No. | Cable | Signal | |
| 1 | R-P | Orange (1 point, red) | 24 VDC+ | |
| 2 | R-N | Gray (1 point, red) | 24 VDC GND | |
| 3 | IB100 | White (1 point, red) | Input | |
| 4 | IB112 | Yellow (1 point, red) | Input | |
| 5 | IB114 | Pink (1 point, red) | Input | |
| 6 | IB116 | Orange (2 point, red) | Input | |
| 7 | IB118 | Gray (2 point, red) | Input | |
| 8 | IB11A | White (2 point, red) | Input | |
| 9 | IB11C | Yellow (2 point, red) | Input | |
| 10 | IB11E | Pink (2 point, red) | Input | |
| 11 | OB110 | Orange (3 point, red) | Output | |
| 12 | OB112 | Gray (3 point, red) | Output | |
| 13 | OB114 | White (3 point, red) | Output | |
| 14 | OB116 | Yellow (3 point, red) | Output | |
| 15 | OB118 | Pink (3 point, red) | Output | |
| 16 | OB11A | Orange (4 point, red) | Output | |
| 17 | OB11C | Gray (4 point, red) | Output | |
| 18 | OB11E | White (4 point, red) | Output | |
| 19 | - | Yellow (4 point, red) | Unused, cannot be connected | |
| 20 | ES11 | Pink (4 point, red) | Emergency stop output 1 | |
| 21 | ES21 | Orange (5 point, red) | Emergency stop output 2 | |
| 22 | EM1 | Gray (5 point, red) | Emergency stop input (*1) | |
| 23 | - | White (5 point, red) | Unused, cannot be connected | |
| 24 | R-P0 | Yellow (5 point, red) | 24 VDC+ | |
| 25 | R-N0 | Pink (5 point, red) | 24 VDC GND | |

CN59 Connector model XM8A-5021 (OMRON)


| CN8 Pin No. | Wire No. | Cable | Signal |
|----------------|-------------|-------------------------|-----------------------------|
| 26 | R-P | Orange (1 point, black) | 24 VDC+ |
| 27 | R-N | Gray (1 point, black) | 24 VDC GND |
| 28 | IB111 | White (1 point, black) | Input |
| 29 | IB113 | Yellow (1 point, black) | Input |
| 30 | IB115 | Pink (1 point, black) | Input |
| 31 | IB117 | Orange (2 point, black) | Input |
| 32 | IB119 | Gray (2 point, black) | Input |
| 33 | IB11B | White (2 point, black) | Input |
| 34 | IB11D | Yellow (2 point, black) | Input |
| 35 | IB11F | Pink (2 point, black) | Input |
| 36 | OB111 | Orange (3 point, black) | Output |
| 37 | OB113 | Gray (3 point, black) | Output |
| 38 | OB115 | White (3 point, black) | Output |
| 39 | OB117 | Yellow (3 point, black) | Output |
| 40 | OB119 | Pink (3 point, black) | Output |
| 41 | OB11B | Orange (4 point, black) | Output |
| 42 | OB11D | Gray (4 point, black) | Output |
| 43 | OB11F | White (4 point, black) | Output |
| 44 | - | Yellow (4 point, black) | Unused, cannot be connected |
| 45 | ES12 | Pink (4 point, black) | Emergency stop output 1 |
| 46 | ES22 | Orange (5 point, black) | Emergency stop output 2 |
| 47 | EM2 | Gray (5 point, black) | Emergency stop input (*1) |
| 48 | R-N1 | White (5 point, black) | Ready input (*1) |
| 49 | R-P0 | Yellow (5 point, black) | 24 VDC+ |
| 50 | R-N0 | Pink (5 point, black) | 24 VDC GND |
| Hood | SG | Shield | Shield |

^{*1} Between NO and EM1: TP emergency stop parallel contact Between EM1 and EM2: External emergency stop TB0 parallel contact

Between N0 and N1: TP ready parallel contact


3) Terminal block TB0

Wire No.



TB0 Model ML-1600-4P (Sato Parts)

* EM1 and EM2 are also connected in parallel with CN59.



TB0

Recommended length of exposed wire for wiring: 9 mm

Available wire: Stranded wire, from 0.3 mm² (AWG22) to 0.75 mm² (AWG20)

4) PC connector port CNPC connection list

[1] Specifications of Ethernet connector

Controller side: Ethernet connector, 8-pin, RJ-45 CAT5 socket

The other side: RJ-45 CAT5 plug

Ethernet connector pin assignment

| Pin No. | Signals | Description |
|---------|---------|--------------------------|
| 1 | TXD+ | Transmission data + side |
| 2 | TXD- | Transmission data – side |
| 3 | RXD+ | Receiving data + side |
| 4 | ı | |
| 5 | ı | |
| 6 | RXD- | Receiving data – side |
| 7 | ı | |
| 8 | - | |

[2] Specifications of Ethernet cable

For the Ethernet cable, use a twisted pair cable with RJ-45 connector by referring to the table below. The Ethernet cable should be prepared by the user.

| Type of Ethernet | Category | Remarks |
|------------------|----------------------|---|
| 10Base-T | Category 3 or higher | To connect a target device via a hub: Straight cable |
| 100Base-TX | Category 5 or higher | • To connect a target device without using a hub: Cross cable |

2.3.4 Connector pins assignment

1) CN51 (Power supply connector)

| CN51 Pin No. | Wire No. | Signals |
|-----------------|----------|-----------|
| 1 | L1 | 200 VAC |
| 2 | L2 | 200 VAC |
| 3 | PE | Grounding |

Controller side connector model: NJC-24-3-RM (UL) (Nanaboshi)

2) CN52A (Servo power supply connector "A" side)

[When 3-axis control type is selected]

CN52A Wire No. Signals Pin No. Grounding Ε Ε U1 Motor (1) Power supply, phase U М Motor (1) Power supply, phase V Α W1 Motor (1) Power supply, phase W Motor (1) Power supply grounding K E1 Motor (2) Power supply, phase U U U2 Ν V2 Motor (2) Power supply, phase V W2 Motor (2) Power supply, phase W В Motor (2) Power supply grounding J E2 U3 Motor (3) Power supply, phase U ٧ ٧3 Motor (3) Power supply, phase V Р W3 Motor (3) Power supply, phase W С E3 Motor (3) Power supply grounding Н NC NC S NC R D NC BR1 Brake power supply (+) NO Brake power supply (-)

[When 4-axis control type is selected]

| CN52A Pin No. | Wire No. | Signals |
|------------------|----------|----------------------------------|
| Е | E | Grounding |
| L | U1 | Motor (1) Power supply, phase U |
| М | V1 | Motor (1) Power supply, phase V |
| Α | W1 | Motor (1) Power supply, phase W |
| K | E1 | Motor (1) Power supply grounding |
| J | U2 | Motor (2) Power supply, phase U |
| Ζ | V2 | Motor (2) Power supply, phase V |
| В | W2 | Motor (2) Power supply, phase W |
| J | E2 | Motor (2) Power supply grounding |
| T | U3 | Motor (3) Power supply, phase U |
| V | V3 | Motor (3) Power supply, phase V |
| Р | W3 | Motor (3) Power supply, phase W |
| O | E3 | Motor (3) Power supply grounding |
| Η | U4 | Motor (4) Power supply, phase U |
| S | V4 | Motor (4) Power supply, phase V |
| R | W4 | Motor (4) Power supply, phase W |
| D | E4 | Motor (4) Power supply grounding |
| G | BR1 | Brake power supply (+) |
| F | NO | Brake power supply (-) |

Controller side connector model: D/MS3102A22-14S (DDK)

3) CN53A (Encoder connector "A" side)

[When 3-axis control type is selected]

CN53A Wire No. Signal Pin No. PG11 Motor (1) Encoder +5 V 1 2 PG12 Motor (1) Encoder 0 V 3 SG1 Motor (1) shield 4 NC 5 PG13 Motor (1) Encoder serial PS 6 PG14 Motor (1) Encoder serial/PS PG21 Motor (2) Encoder +5 V 8 PG22 Motor (2) Encoder 0 V 9 SG2 Motor (2) shield 10 NC Motor (2) Encoder serial PS 11 PG23 PG24 12 Motor (2) Encoder serial/PS 13 NC 14 PG31 Motor (3) Encoder +5 V 15 PG32 Motor (3) Encoder 0 V 16 Motor (3) shield SG3 17 NC 18 PG33 Motor (3) Encoder serial PS 19 PG34 Motor (3) Encoder serial/PS 20 NC NC 21 22 NC 23 NC 24 NC 25 NC

[When 4-axis control type is selected]

| CN53A Pin No. | Wire No. | Signal |
|------------------|----------|-----------------------------|
| 1 | PG11 | Motor (1) Encoder +5 V |
| 2 | PG12 | Motor (1) Encoder 0 V |
| 3 | SG1 | Motor (1) shield |
| 4 | NC | |
| 5 | PG13 | Motor (1) Encoder serial PS |
| 6 | PG14 | Motor (1) Encoder serial/PS |
| 7 | PG21 | Motor (2) Encoder +5 V |
| 8 | PG22 | Motor (2) Encoder 0 V |
| 9 | SG2 | Motor (2) shield |
| 10 | NC | |
| 11 | PG23 | Motor (2) Encoder serial PS |
| 12 | PG24 | Motor (2) Encoder serial/PS |
| 13 | NC | |
| 14 | PG31 | Motor (3) Encoder +5 V |
| 15 | PG32 | Motor (3) Encoder 0 V |
| 16 | SG3 | Motor (3) shield |
| 17 | NC | |
| 18 | PG33 | Motor (3) Encoder serial PS |
| 19 | PG34 | Motor (3) Encoder serial/PS |
| 20 | PG41 | Motor (4) Encoder +5 V |
| 21 | PG42 | Motor (4) Encoder 0 V |
| 22 | SG4 | Motor (4) shield |
| 23 | NC | |
| 24 | PG43 | Motor (4) Encoder serial PS |
| 25 | PG44 | Motor (4) Encoder serial/PS |

Controller side connector model: XM2D-2501 (OMRON)

4) CN52B (Servo power supply connector "B" side)

| Wire No. | Signals |
|----------|---|
| Е | Grounding |
| U4 | Motor (4) Power supply, phase U |
| V4 | Motor (4) Power supply, phase V |
| W4 | Motor (4) Power supply, phase W |
| E4 | Motor (4) Power supply grounding |
| U5 | Motor (5) Power supply, phase U |
| V5 | Motor (5) Power supply, phase V |
| W5 | Motor (5) Power supply, phase W |
| E5 | Motor (5) Power supply grounding |
| U6 | Motor (6) Power supply, phase U |
| V6 | Motor (6) Power supply, phase V |
| W6 | Motor (6) Power supply, phase W |
| E6 | Motor (6) Power supply grounding |
| NC | |
| NC | |
| NC | |
| NC | |
| BR2 | Brake power supply (+) |
| NO | Brake power supply (-) |
| | E U4 V4 W4 E4 U5 V5 W5 E5 U6 V6 W6 E6 NC NC NC NC BR2 |

Controller side connector model: D/MS3102A22-14S (DDK)

5) CN53B (Encoder connector "B" side)

| CN53B | | |
|---------|----------|-----------------------------|
| Pin No. | Wire No. | Signal |
| 1 | PG41 | Motor (4) Encoder +5 V |
| 2 | PG42 | Motor (4) Encoder 0 V |
| 3 | SG4 | Motor (4) shield |
| 4 | NC | |
| 5 | PG43 | Motor (4) Encoder serial PS |
| 6 | PG44 | Motor (4) Encoder serial/PS |
| 7 | PG51 | Motor (5) Encoder +5 V |
| 8 | PG52 | Motor (5) Encoder 0 V |
| 9 | SG5 | Motor (5) shield |
| 10 | NC | |
| 11 | PG53 | Motor (5) Encoder serial PS |
| 12 | PG54 | Motor (5) Encoder serial/PS |
| 13 | NC | |
| 14 | PG61 | Motor (6) Encoder +5 V |
| 15 | PG62 | Motor (6) Encoder 0 V |
| 16 | SG6 | Motor (6) shield |
| 17 | NC | |
| 18 | PG63 | Motor (6) Encoder serial PS |
| 19 | PG64 | Motor (6) Encoder serial/PS |
| 20 | NC | |
| 21 | NC | |
| 22 | NC | |
| 23 | NC | |
| 24 | NC | |
| 25 | NC | |

Controller side connector model: XM2D-2501 (OMRON)

6) CN54A, B (Feeder power supply connector "A" side, "B" side)

| CN54A, B Pin No. | Wire No. | Signals |
|---------------------|----------|-----------|
| 1 | Е | Grounding |
| 2 | L10 | 200 VAC |
| 3 | L20 | 200 VAC |

Controller side connector model: NJC-20-3-RF (UL) (Nanaboshi)

7) CN55A, B (Feeder control connector "A" side, "B" side)

| CN55 "A" side Pin No. | Wire No. | Signal |
|--------------------------|----------|--------------------|
| 1 | P0 | 24 VDC+ |
| 8 | N0 | 24 VDC GND |
| 2 | OB107 | RB1 Screw feed |
| 9 | SB-IN1 | Spare |
| 3 | SB-OT0 | Spare |
| 10 | SB-OT1 | Spare |
| 4 | IB109 | RB1 Screw shortage |
| 11 | SB-OT3 | Spare |
| 5 | NC | |
| 12 | NC | |
| 6 | NC | |
| 13 | NC | |
| 7 | NC | |
| 14 | NC | |

| CN55 "B" side Pin No. | Wire No. | Signal |
|--------------------------|----------|--------------------|
| 1 | P0 | 24 VDC+ |
| 8 | N0 | 24 VDC GND |
| 2 | OB10F | RB2 Screw feed |
| 9 | SD-IN1 | Spare |
| 3 | SD-OT0 | Spare |
| 10 | SD-OT1 | Spare |
| 4 | IB111 | RB2 Screw shortage |
| 11 | SB-OT3 | Spare |
| 5 | NC | |
| 12 | NC | |
| 6 | NC | |
| 13 | NC | |
| 7 | NC | |
| 14 | NC | |

Controller side connector model: XM8L-1423 (OMRON)

8) CN56A, B (Driver power supply connector)

| CN56A, B Pin No. | Wire No. | Signals |
|---------------------|----------|-----------|
| 1 | E | Grounding |
| 2 | L10 | 200 VAC |
| 3 | L20 | 200 VAC |

Controller side connector model: NJC-20-3-RF (UL) (Nanaboshi)

9) CN57A, B (Driver control connector)

| CN57 "A" side Pin No. | Wire No. | Signal | | | | |
|--------------------------|----------|--------------------------|--|--|--|--|
| 1 | P0 | 24 VDC+ | | | | |
| 13 | P0 | 24 VDC+ | | | | |
| 2 | N0 | 24 VDC GND | | | | |
| 14 | N0 | 24 VDC GND | | | | |
| 3 | OB108 | RB1 Start | | | | |
| 15 | OB109 | RB1 Torque selection 1 | | | | |
| 4 | OB10A | RB1 Torque selection 2 | | | | |
| 16 | OB10B | RB1 Torque selection 4 | | | | |
| 5 | OB10C | RB1 Torque selection 8 | | | | |
| 17 | SA-IN5 | Spare | | | | |
| 6 | SA-IN6 | Spare | | | | |
| 18 | SA-IN7 | Spare | | | | |
| 7 | SA-OT0 | Spare | | | | |
| 19 | IB10A | RB1 Tightening completed | | | | |
| 8 | IB10B | RB1 Tightening time over | | | | |
| 20 | IB10C | RB1 Alarm | | | | |
| 9 | SA-OT4 | Spare | | | | |
| 21 | SA-OT5 | Spare | | | | |
| 10 | SA-OT6 | Spare | | | | |
| 22 | SA-OT7 | Spare | | | | |
| 11 | NC | | | | | |
| 23 | NC | | | | | |
| 12 | NC | | | | | |
| 24 | NC | | | | | |

| CN57 "B" side Pin No. | Wire No. | Signal |
|--------------------------|----------|--------------------------|
| 1 | P0 | 24 VDC+ |
| 13 | P0 | 24 VDC+ |
| 2 | N0 | 24 VDC GND |
| 14 | N0 | 24 VDC GND |
| 3 | OB110 | RB2 Start |
| 15 | OB111 | RB2 Torque selection 1 |
| 4 | OB112 | RB2 Torque selection 2 |
| 16 | OB113 | RB2 Torque selection 4 |
| 5 | OB114 | RB2 Torque selection 8 |
| 17 | SC-IN5 | Spare |
| 6 | SC-IN6 | Spare |
| 18 | SC-IN7 | Spare |
| 7 | SC-OT0 | Spare |
| 19 | IB112 | RB2 Tightening completed |
| 8 | IB113 | RB2 Tightening time over |
| 20 | IB114 | RB2 Alarm |
| 9 | SC-OT4 | Spare |
| 21 | SC-OT5 | Spare |
| 10 | SC-OT6 | Spare |
| 22 | SC-OT7 | Spare |
| 11 | NC | |
| 23 | NC | |
| 12 | NC | |
| 24 | NC | |

Controller side connector model: XM8L-2423 (OMRON)


10) CNTP (Teaching Pendant connector)

| CNTP | | |
|---------|----------|-----------------------------------|
| Pin No. | Wire No. | Signal |
| 1 | FG | Frame ground |
| 2 | TXD | TXD |
| 3 | DTR | DTR |
| 4 | RXD | RXD |
| 5 | DSR | DSR |
| 6 | RTS | RTS |
| 7 | CTS | CTS |
| 8 | NC | |
| 9 | NC | |
| 10 | SG | Signal ground |
| 11 | NC | |
| 12 | N0 | SWCOM (SW-COM) |
| 13 | N1 | CW1 (Ready switch) |
| 14 | NC | SW2 |
| 15 | NC | SW3 |
| 16 | NC | SW4 |
| 17 | NC | |
| 18 | N0 | 24 VDC GND (Pendant power supply) |
| 19 | N0 | 24 VDC GND (Pendant power supply) |
| 20 | EM1 | ESW-1 (Emergency stop switch) |
| 21 | JUMP | ESW-1 |
| 22 | JUMP | ESW-2 |
| 23 | N0 | ESW-2 (Emergency stop switch COM) |
| 24 | N0 | DSW-1 (Deadman SW-COM) |
| 25 | JUMP | DSW-1 |
| 26 | JUMP | DSW-2 |
| 27 | IB102 | DSW-2 (Deadman switch) |
| 28 | N0 | KSW-C (Key SW-COM) |
| 29 | NC | KSW-1 |
| 30 | IB103 | KSW-2 (Key switch) |
| 31 | NC | Spare switch |
| 32 | NC | Spare switch |
| 33 | NC | |
| 34 | NC | |
| 35 | NC | |
| 36 | P0 | 24 VDC+ (Pendant power supply) |
| 37 | P0 | 24 VDC+ (Pendant power supply) |


Controller side connector model: XM2D-3701 (OMRON)


2.3.5 Outside dimensions

1) Robot controller RC5500-S



2) Teaching pendant RC5500TS





2.3.6 Robot controller inside parts location

- 1) Internal layout
- [1] MC unit (Machine controller)

Model: JEPMC-MC2310 (Yaskawa Electric Corp.)

The MC unit incorporates the following units:

Communication module

Model: JAPMC-CM2310 217IF-01 (Yaskawa Electric

Corp.)
I/O module

Model: JEPMC-IO2303 LIO-04 (Yaskawa Electric

Corp.)

[2] Power supply

Model: PBA100F-24-J (Cosel)

[3] Sixth axis (Axis 6) Servo pack (For two Z-type robots only)

Model: See the table below.

[4] Fifth axis (Axis 5) Servo pack (For two-type robots only)

Model: See the table below.

[5] Fourth axis (Axis 4) Servo pack (For two-type robots only)

Model: See the table below.

[6] Third axis (Axis 3) Servo pack (For Z-type robot only)

Model: See the table below.

[7] Second axis (Axis 2) Servo pack


Model: See the table below.


[8] First axis (Axis 1) Servo pack

Model: See the table below.

| Motor output (W) | Model of servo pack |
|------------------|---------------------|
| 100W | SGDV-R90A11A |
| 200W | SGDV-1R6A11A |
| 400W | SGDV-2R8A11A |
| 750W | SGDV-5R5A11A |

^{*} Yaskawa Electric Corp.





Example: for SR560Y θ -Z, the first axis = 200 W, the second axis = 100 W, and the third axis = 100 W.

[9] PI-50-01 PCB

For terminal block layout on the PCB, refer to "2.3.7 CN-50-01 Layout of terminal block on PCB".

[10] Terminal block TB4
Terminal block layout



[11] Terminal block TB2
Terminal block layout

| L1C | L2C | L1C L2C | L1C | L2C | L10 | L20 | L10A | L20A |
|-----|-----|------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|
|-----|-----|------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|

2.3.7 PI-50-01 Layout of terminal block on PCB

- 1) PI-50-01 PCB
- [1] TB1

(Standard I/O-1 input terminal block)

[2] TB2 (Standard I/O-1 output terminal block)


| Terminal block layout |
|-----------------------|
| IB10F |
| IB10E |
| IB10D |
| IB10C |
| IB10B |
| IB10A |
| IB109 |
| IB108 |
| IB107 |
| IB106 |
| IB105 |
| IB104 |
| N1 |

| Terminal block layout |
|-----------------------|
| OB10F |
| OB10E |
| OB10D |
| OB10C |
| OB10B |
| OB10A |
| OB109 |
| OB108 |
| OB107 |
| OB106 |
| OB105 |
| OB104 |
| OB103 |
| OB102 |


[3] TB3
(Standard I/O-2 input terminal block)

| Standard 1/O-2 ii | ıpu |
|-----------------------|-----|
| terminal block |) |
| | |
| Terminal block layout | |
| IB11F | |
| IR11E | |

IB11C
IB11B
IB11A
IB119
IB118
IB117
IB116
IB115
IB114
IB113
IB111
IB111
IB111



| Terminal block layout |
|-----------------------|
| OB11F |
| OB11E |
| OB11D |
| OB11C |
| OB11B |
| OB11A |
| OB119 |
| OB118 |
| OB117 |
| OB116 |
| OB115 |
| OB114 |
| OB113 |
| OB112 |
| OB111 |
| OB110 |



[5] TB5 (N0 terminal block: 24 VDC GND)

| Terminal block layout |
|-----------------------|
| N0 |

[6] TB6 (P0 terminal block: 24 VDC+)

| E | Terminal block layout |
|---|-----------------------|
| Ī | P0 |
| | P0 |
| | P0 |
| | P0 |
| I | P0 |
| | P0 |
| | P0 |
| | P0 |

[7] TB7 (N terminal block: 24 VDC GND)

| Terminal block layout |
|-----------------------|
| N |
| N |
| N |
| N |
| N |

[8] TB8 (P terminal block: 24 VDC+)

| Terminal block layout | |
|-----------------------|---|
| Р | l |
| Р | l |
| Р | l |
| Р | l |
| Р | l |

TB1, TB2, TB3, TB4: Model ML1900-V-**P (Sato Parts)

Standard unsheathed wire length: 10 mm

Applicable wire: Stranded wire, 0.2 mm² (AWG24) to 0.75 mm² (AWG20)

^{*} Specifications of each terminal block

TB5, TB6, TB7, TB8: Model ML800S1V-**P (Sato Parts)

Standard unsheathed wire length: 11 mm

Applicable wire: Stranded wire, 0.3 mm² (AWG22) to 1.25 mm² (AWG16)

[9] SW1 (RB1 Motor holding brake compulsory release switch)

This switch is used to forcedly reset the robot (1) motor holding brake.

Even if the CPU is stopped and the teaching pendant cannot be used, the motor holding brake can be released while this switch is being pressed.

[10] SW2 (RB2 Motor holding brake compulsory release switch)

This switch is used to forcedly reset the robot (2) motor holding brake.

Even if the CPU is stopped and the teaching pendant cannot be used, the motor holding brake can be released while this switch is being pressed.

[11] TB9

(Terminal block for emergency stop output)

| Terminal block layout | |
|-----------------------|--|
| ES22 | |
| ES21 | |
| ES12 | |
| ES11 | |

[12] TB12

[14] TB13

(Terminal block for feeder "A" side control signal spare)

(Terminal block for feeder "B" side control signal spare)

| Terminal block layout | |
|-----------------------|--|
| SB-OT3 | |
| SB-OT1 | |
| SB-OT0 | |
| SB-IN1 | |

| | Terminal block layout |
|---|-----------------------|
| Ī | SD-OT3 |
| [| SD-OT1 |
| [| SD-OT0 |
| ſ | SD-IN1 |

[13] TB10


[15] TB11

(Terminal block for driver "A" side control signal spare)

(Terminal block for driver "B" side control signal spare)

| Terminal block layout |
|-----------------------|
| SA-OT7 |
| SA-OT6 |
| SA-OT5 |
| SA-OT4 |
| SA-OT0 |
| SA-IN7 |
| SA-IN6 |
| SA-IN5 |

| Terminal block layout |
|-----------------------|
| SC-OT7 |
| SC-OT6 |
| SC-OT5 |
| SC-OT4 |
| SC-OT0 |
| SC-IN7 |
| SC-IN6 |
| SC-IN5 |




TB10, TB11, TB12, TB13: Model ML700NV-**P (Sato Parts)


Standard unsheathed wire length: 9 to 10 mm $\,$

Applicable wire: Stranded wire, 0.08 mm² (AWG28) to 0.32 mm² (AWG22)

2.3.8 CN-50-01 PCB short-circuit pin

1) CN-50-01 PCB





[1] SP1 (24 VDC external output setting)

- 1-2: "P" (internal 24 VDC) external output is enabled.
- 2-3: "P" (internal 24 VDC) external output is disabled. (Standard)

[2] SP2 (24 VDC external output setting)

- 1-2: "P" (internal 24 VDC) external output is enabled.
- 2-3: "P" (internal 24 VDC) external output is disabled. (Standard)

[3] SP3 to SP7 (Input signal assignment setting)

| Short-circuit | I/O N | Setting | | D 1 |
|---------------|---------|--------------------|--------------------------|---------------------|
| pin No. | I/O No. | 1–2 | 2–3 | Remarks |
| SP3 | IB110 | | | |
| SP4 | IB111 | CN58B | CN59 | D. (2 12 |
| SP5 | IB112 | (Used for standard | (Used for standard I/O-2 | Between 2 and 3, as |
| SP6 | IB113 | I/O-1B connector) | side connector) | standard setting |
| SP7 | IB114 | | | |

2. Installation

[4] SP8 to SP12 (Output signal assignment setting)

| Short-circuit LON | | Setting | | D | |
|-------------------|---------|--------------------|--------------------------|---------------------|--|
| pin No. | I/O No. | 1–2 | 2–3 | Remarks | |
| SP8 | OB110 | | | | |
| SP9 | OB111 | CN58B | CN59 | D. 4 2 1 2 | |
| SP10 | OB112 | (Used for standard | (Used for standard I/O-2 | Between 2 and 3, as | |
| SP11 | OB113 | I/O-1B connector) | side connector) | standard setting | |
| SP12 | OB114 | | | | |

2.4 Maintenance and inspection

Be sure to disconnect the power cable of the robot controller before maintenance and inspection.

- 1) Check points
 - Check the voltage supplied to the controller.
 - Check the cooling fan (FAN0) filter.
 - Check the connectors.
 - Check the cables.

- → Should be within the specified range, or within the range between 200 VAC to 230 VAC.
- \rightarrow Check for clog in the filter.
- → Check for looseness or gap.
- → Check for disconnection or damages.

- 2) Inspection intervals
 - · Every six months
- 3) Consumables

It recommended to keep spare consumables at your hand.

- Cables
- MC unit battery (1 pce.) → Replacement interval: Approximately five years
 Model: JZSP-BA01 (Yaskawa Electric Corp.)
- Absolute value encoder battery \rightarrow Replacement interval: Approximately five years
 - Model: ER6VC4 (Toshiba Denchi)
- Battery for teaching pendant (1 pce.) → Replacement interval: Approximately five years Model: GT11-50BAT (Matsushita Electric Works, Ltd.)

Note) When replacing the battery, be sure to refer to "3.1 Replacing battery". Otherwise, data stored in the controller may be lost and irretrievable.

3. Appendix

3.1 Replacing battery

1. MC unit battery

The MC unit incorporates a replaceable battery. This battery is intended for backup of the programs and data stored into the MC unit to prevent them from being lost when power supplied to the MC unit is shut off (due to power failure).

Service life of the battery is approximately five years.

Backup of data in the memory against power failure is possible until the total power failure period reaches a year. It may differ depending on the operating conditions, including ambient temperature.

When the "BATTERY ALARM" indicator on the "ROBOT (*) FAULT" screen of the teaching pendant is highlighted (when the "BAT" LED of the MC unit is lit up), be sure to replace the battery with new one within two weeks. Otherwise, programs and data stored in the MC unit memory will be lost.


Preparation

1) Save of programs and data in memory

Prior to replacement of a battery, save the programs and data stored in the MC unit into the hard disc of the PC. The saved programs and data can be used in the case that those in the memory are deleted by mistake during the replacement of a battery.

2) Preparation of spare battery

Prepare a spare battery (model: JZSP-BA01).



JZSP-BA01 (Yaskawa Electric Corp.)

Replacing battery


- 1) Remove the screws on the left side of the robot controller, and open the door.
- Supply power to the robot controller, and turn on the power switch.
 At this time, press the emergency stop switch of the teaching pendant or the same connected externally by way of precaution to enter the emergency stop status.





When power is supplied with the side door of the robot controller opened, power voltage is supplied to the robot controller. DO NOT touch the power terminals. Otherwise, you may suffer electric shock.

3) Ensure that the "RDY" LED on the MC unit to the upper right on the robot controller right side is lit up.



- 4) Open the battery cover on the lower side of the MC unit.
- 5) Disconnect the connector at the end of the lead wire of the battery from the connector of the MC unit, and remove the battery from the battery holder.
- 6) Securely plug the connector at the end of the replacement battery to the connector of the MC unit. Then, load the replacement battery into the battery holder. (After the battery is loaded into the battery holder, you cannot put your finger in the connector, since the space around the connector is narrow.)
- 7) Make sure that the "BAT" LED of the MC unit is lit up (the "battery alarm" lamp of the teaching pendant is unlit).
- 8) Close the battery cover.
- 9) Turn off the power switch of the controller, and fix the door with the screws.

When the steps shown above are finished, replacement of the battery is completed.






Be sure to replace the MC unit battery with power supplied to the MC unit. Otherwise, programs and data stored in the unit memory may be lost.

2. Absolute value encoder battery

In the robot controlled by the robot controller RC5500 Series, the absolute value encoder is used for detection of position. In the relay box of the robot, absolute encoder batteries are provided for each of the equipped axes of the robot. These batteries are intended for backup of current position data stored in the encoder to prevent them from being deleted when power supplied to the encoder is shut off (due to power failure). Service life of the battery is approximately five years. It may differ depending on the operating conditions, including ambient temperature.

• Preparation

Preparation of spare batteryPrepare spare batteries (model: ER6VC4) for each of the axes of the robot.




ER6VC4 (Toshiba Denchi)

Replacing battery

- 1) Supply power to the robot controller, and turn on the power switch.
- 2) Press the emergency stop switch of the teaching pendant or the same connected to the outside to enter the emergency stop status. Make sure that the "RUN" lamp in front of the robot controller is lit up.
- 3) Remove the screws of the robot relay box (see the figure shown below), disconnect the battery connector connected to the encoder battery connecting PCB "EC-01-02" (see the figure on the next page), and remove all the old batteries from the battery holder.




Front view of robot controller



4) First, prepare a new battery, and securely plug the connector at the end of the lead wire of the battery to the battery connector (BA1 to BA4) on the PCB EC-01-02. Then, load the battery to the battery holder. Load all the batteries for the axes in a similar manner.

Connect the battery for the first axis to the BA1, the same for the second axis to the BA2, the same for the third axis to the BA3, and the same for the fourth axis to the BA4.



Battery connection PCB EC-01-02

- 5) Make sure that all the batteries are securely loaded. Then, turn off the power switch of the robot controller to reset the "Absolute value encoder battery alarm (Servo pack alarm code A.830)" and "Absolute value encoder battery warning (Servo pack alarm code A930)".
- 6) Wait for approximately ten seconds with power shut off. Then, turn on the power switch of the robot controller again. Battery replacement is complete if no alarm is issued.

If the absolute value encoder battery is disconnected with power to the robot controller shut off (when the encoder cable is disconnected, or the connector CN3B-BAT on the PCB EC-01-02 is disconnected), data in the absolute value encoder is lost. In such a case, setup of the absolute value encoder is required. For setup of the encoder, refer to "3.2 Encoder setup (initialization) procedure".

Battery for teaching pendant


The teaching pendant is equipped with the battery to store clock data, alarm history and recipe data. The battery service life is approx. 5 years. However, it may vary depending on operating conditions (ambient temperature, etc.).

Preparation

1) Saving memory data


Before battery replacement, save the data in the teaching pendant into the PC hard disk, etc. The saved program and data should be used, in case where memory data are accidentally erased by a battery replacement failure, etc.

Preparing a battery for replacement
 Prepare a battery for replacement (Model: GT11-50BAT).



Replacing battery

- Turn OFF the power supply for the robot controller, and turn OFF the power supply for the teaching pendant.
- 2) Loosen the environmental-resistant back cover screws at four places on the back of the teaching pendant, and remove the cover.
- 3) Remove the used battery from the holder.
- 4) Disconnect the connector of the battery, and insert the connector of a new battery within 30 seconds.
- 5) Insert the new battery into the holder.
- Re-mount the environmental-resistant back cover, and tighten the screws.
- Turn ON the power switch of the robot controller.
 Unless an alarm is activated, the replacement procedure is completed.



If data in the teaching pendant are accidentally erased, download backup data, and conduct required setting procedure (clock setting).

3.2 Encoder reset (initialization) procedure

In the robot controlled by the robot controller RC5500 Series, the absolute value encoder is used for detection of position. Thus, even when power is turned on, calibration of origin is unnecessary, leading to drastic reduction in the time required for startup of the machine. However, in the cases shown below, encoder reset (initialization) is required. It can be performed against your intended axes only, since it is carried out for each axis individually. After the encoder reset is completed, be sure to perform the setup of origin described in the section 3.3 to decide the origin (zero point) of the encoder.

When encoder reset is required

- When encoder backup alarms (servo pack error codes A.810 or A.820) are issued
- When encoder extension cables for each axis are disconnected
- When the absolute value encoder battery is removed or CN3B-BAT connector on the PCB EC-50-01 is disconnected with power to the robot controller shut off.
- When the motor is replaced.

Reset of the absolute value encoder is valid only while the servo motor is in the OFF status. After the reset is completed, supply power again.

Carry out the origin setup only when it is necessary. Coordinate system of a point of which teaching has already been finished is altered, and the arm may move unexpectedly, if it is operated with the coordinate system altered.








After the encoder setup is finished, be sure to carry out the "origin setup". Coordinate system of a point of which teaching has already been finished is altered, and the arm may move unexpectedly, if it is operated with the coordinate system altered.

• Encoder reset procedure


(For details of the teaching pendant operating procedure, refer to "Advanced Thread Tightening Robot nitoman RC5500TS Teaching Pendant Operation Manual".)

- 1) Check if the teaching pendant is connected to the robot controller. If the teaching pendant is not connected, connect it to the robot controller.
- 2) Turn ON the power supply to the robot controller, and turn ON the power switch.
- 3) Press the teaching pendant emergency stop switch to bring the robot into emergency stop status.
- 4) Insert the teaching mode selector key switch into the teaching pendant, and turn the key to the "TEACH ON" side.




Teaching pendant


- 5) Open the initial screen of the teaching pendant, and press the [SETUP MENU] switch ([1] in the figure below).
- 6) A window opens, allowing you to select the robot to be set up. To set up ROBOT (1), press the [ROBOT (1) SETUP] switch ([2] in the figure below). However, when a single standard thread tightening robot is used, this screen will be skipped, and the ROBOT (1) SETUP MENU screen automatically opens.



7) The SETUP MENU screen opens. Touch the [ADVANCED MODE DISABL] display field at the bottom of the screen ([3] in the figure below) three times. Then, [ADVANCED MODE ENABLE] is displayed. At the same time, the [ADVANCED MODE] selector switch on the right side ([4] in the figure below) lights up in light blue. If you press the [ADVANCED MODE] selector switch in this status, the display changes to the SETUP (ADVANCED) MENU screen.




8) If you press the [ENCODER RESET] switch on the SETUP (ADVANCED) MENU screen, the display will switch to the ENCODER RESET screen.




ROBOT (1) SETUP (ADVANCED) MENU screen

- 9) Select an axis subject to encoder reset processing among the axis name indication switches (Y1, A1 and Z1) ([6] in the figure below). The switch for the selected axis lights up in green.
 - * For the axis that has not been selected in this step, encoder reset processing will not be executed. For example, the following screen is displayed in the case of encoder reset processing for all three axes (Y1, A1 and Z1).




ROBOT (1) ENCODER RESET screen

10) Touch the [RESET IMPOSSIBLE] switch ([7] in the figure below) three times, to change the indication to [RESET POSSIBLE].




ROBOT (1) ENCODER RESET screen

11) Press the [RESET] switch ([8] in the figure below).




ROBOT (1) ENCODER RESET screen


12) A confirmation window opens again, asking if you intend to reset the encoder. If you intend to reset the encoder, press [YES] ([9] in the figure below). If you do not intend to reset the encoder, press [CANCEL] ([10] in the figure below).



ROBOT (1) ENCODER RESET screen

13) If you press [YES] ([9] in the above figure), the "ENCODER IS BEING RESET" message appears at the center of the confirmation window. Then, the window automatically closes, and RC5500-TS completes the encoder reset processing. In this status, the indication on the axis name switch changes from [RESET INCOMPLETE] to [RESET COMPLETE].





ROBOT (1) ENCODER RESET screen

ROBOT (1) ENCODER RESET screen

14) Turn OFF the power supply for the robot controller. Wait for at least 10 seconds in this status, and then turn ON the power supply again.

Then, the encoder reset is finished.

To decide the origin (zero point) of the encoder for all the axes that the encoder reset has been completed, be sure to carry out the origin setup described in section 3.3.

3.3 Origin setup

In the robot controlled by the robot controller RC5500 Series, the absolute value encoder is used for detection of position. Thus, even when power is supplied to the machine, calibration of origin is unnecessary, leading to drastic reduction in the time required for startup of the machine. Although the origin (zero point) setup has been completed before shipment, it is mechanically required in the cases show below.

Carry out the origin setup only when it is necessary. Coordinate system of a point of which teaching has already been finished is altered, and the arm may move unexpectedly, if it is operated with the coordinate system altered.

When origin setup is required

- When encoder reset (refer to the previous section "3.2 Encoder reset") is performed.
- When the origin is required to be changed.



WARNING




After the origin setup, be sure to check the position that teaching has already been completed with using the teaching pendant. Especially, if the setup origin has been altered intentionally, coordinate system of the point that teaching has already been finished differs from that after the origin setup. When the arm is operated with the coordinate system altered, it may move unexpectedly. After the origin setup is intentionally performed, be sure to carry out teaching for all the points. Delete all the points used by way of precaution.

Origin setup procedures

(For details of operating procedures of the teaching pendant, refer to the "Operation Manual for Advanced Thread Tightening Robot Nitoman RC5500TS Teaching Pendant".)

Before pushing the robot arm with hands to move to the origin for origin setup, select the "SERVO OFF" on the "JOG" screen via the "TEACH MENU" screen of the teaching pendant, or cancel the operation ready status by pressing the emergency stop switch. Procedures of moving after entering the emergency stop status are shown below.

- 1) Ensure that the teaching pendant is connected to the robot controller. If it is not connected, connect the teaching pendant to the robot controller.
- 2) Supply power to the robot controller, and turn on the power switch.
- 3) Press the emergency switch of the teaching pendant to enter the emergency stop status.
- 4) Insert the teaching selector key switch into the specified position of the teaching pendant, and set it to the "TEACH ON" position.




Teaching Pendant

5) Push each axis to the origins shown on the next page with hands. For the robot with the Z-axis, including SR565Yθ-Z, follow the following steps: open the "BRAKE RELEASE" screen of the teaching pendant, release the Z-axis holding brake, push up the Z-axis to the uppermost end with hands, and actuate the holding brake. (For details of operating procedures of the teaching pendant, refer to the "Operation Manual for Advanced Thread Tightening Robot Nitoman RC5500TS Teaching Pendant". For details of operating procedures of the holding brake, refer to "3.4 Releasing holding brake".)


Origin of SR565Y θ type robot

- i) First axis (Axis 1) [Axis name: Y1]
 - Y1-axis Rear end
- ii) Second axis (Axis 2) [Axis name: A1]




(Right end viewed from front of robot)


iii) Third axis (Axis 3) [Axis name: Z1] (SR565Y θ -Z only) Release of holding brake is required




- 6) Open the "INIT" screen of the teaching pendant, and touch the "SETUP MENU" switch ([1] shown in the figure below).
- 7) A window opens, allowing you to select the robot to be set up. To set up ROBOT (1), press the [ROBOT (1) SETUP] switch ([2] in the figure below). However, when a single standard thread tightening robot is used, this screen will be skipped, and the ROBOT (1) SETUP MENU screen automatically opens.



The SETUP MENU screen opens. Touch the [ADVANCED MODE DISABL] display field at the bottom of the screen ([3] in the figure below) three times. Then, [ADVANCED MODE ENABLE] is displayed. At the same time, the [ADVANCED MODE] selector switch on the right side ([4] in the figure below) lights up in light blue. If you press the [ADVANCED MODE] selector switch ([4] in the figure below) in this status, the display changes to the SETUP (ADVANCED) MENU screen.




9) Touch the "ORIGIN SETUP" switch ([5] shown in the figure below) on the "SETUP (ADVANCED) MENU" screen to access to the "ORIGIN SETUP" screen.




ROBOT (1) SETUP (ADVANCED) MENU screen

- 10) Select an axis subject to origin setup processing among the axis name indication switches (Y1, A1 and Z1) ([6] in the figure below). The switch for the selected axis lights up in green.
 - * Origin setup processing will not be executed for the axis that has not been selected in this step. For example, the following screen is displayed in the case of origin setup processing for two axes (Y1 and A1).




ROBOT (1) ORIGIN SETUP screen

11) Touch the "DISABLE SETUP" switch ([7] shown in the figure below) three times. Then, message "ENABLE SETUP" is indicated.




ROBOT (1) ORIGIN SETUP screen

12) Touch the "ORIGIN SETUP" switch ([8] shown in the figure below).



ROBOT (1) ORIGIN SETUP screen

13) Field indicating message "SETS UP THE ORIGIN. ARE YOU SURE?" appears in the lower part of the screen to confirm the setup. If you want to setup the origin, touch the "YES" switch ([9] shown in the figure below). If you do not want, touch the "CANCEL" switch ([10] shown in the figure below).



ROBOT (1) ORIGIN SETUP screen

14) When the "YES" switch ([9] shown in the figure below) is touched, message "ORIGIN SETUP COMPLETED!" appears in the center of the confirmation window. Then, the window closes automatically.



ROBOT (1) ORIGIN SETUP screen



ROBOT (1) ORIGIN SETUP screen

Then, the origin setup is completed.

Be sure to check the position that teaching has already been performed with using the teaching pendant.

3.4 Releasing holding brake

For the robot equipped with the vertical motion axis, including $SR565Y\theta$ -Z, the holding brake is provided to prevent dropping when power is shut off. In normal operation, release/actuation of the holding brake is automatically controlled interlocking with the ON/OFF status of the servo motor. However, the holding brake should be released compulsorily in the cases shown below.

When the holding brake should be released compulsorily

- When the direct teaching is performed.
- When the origin is setup.
- When the Z-axis is required to be moved compulsorily for installation of the robot.

While the servo motor is in the ON status, the holding brake cannot be released. Select "SERVO OFF" on the "JOG" screen via the "TEACH MENU" screen of the teaching pendant, or cancel the operation ready status by pressing the emergency stop button. Procedures to release the holding brake after setting the machine to the emergency stop status are shown below.

To release the holding brake compulsorily, perform either of the two steps shown below.


- 1. Release by teaching pendant
- 2. Use of compulsory release switch on PCB PI-50-01 in robot controller

Detailed procedures are shown below.

Release by teaching pendant


(For details of the operating procedures of the teaching pendant, refer to the "Operation Manual for Advanced Thread Tightening Robot Nitoman RC5500TS Teaching Pendant".)

- 1) Ensure that the teaching pendant is connected to the robot controller. If it is not connected, connect the teaching pendant to the robot controller.
- 2) Supply power to the robot controller, and turn on the power switch.
- 3) Press the emergency switch of the teaching pendant to enter the emergency stop status.
- 4) Insert the teaching selector key switch into the specified position of the teaching pendant, and set it to the "TEACH ON" position.



Teaching Pendant


- 5) Open the "INIT" screen of the teaching pendant, and touch the "SETUP MENU" switch ([1] shown in the figure below).
- 6) A window opens, allowing you to select the robot to be set up. To set up ROBOT (1), press the [ROBOT (1) SETUP] switch ([2] in the figure below). However, when a single standard thread tightening robot is used, this screen will be skipped, and the ROBOT (1) SETUP MENU screen automatically opens.



7) The SETUP MENU screen opens. Touch the [ADVANCED MODE DISABL] display field at the bottom of the screen ([3] in the figure below) three times. Then, message "ADVANCED MODE ENABLED" is indicated, and the "ADVANCED MODE" switch ([4] shown in the figure below) is highlighted in light blue. In this status, touch the "ADVANCED MODE" switch ([4] shown in the figure below). Then, the "SETUP (ADVANCED) MENU" screen appears.




8) Touch the "RELEASE BRAKE" switch ([5] shown in the figure below) on the "SETUP (ADVANCED) MENU" screen.




ROBOT (1) SETUP (ADVANCED) MENU screen

9) While touching the "AUX OPERATE" switch ([6] shown in the figure below) in the lower left part of the screen, touch the "BRAKE OPERATION" switch ([7] shown in the figure below) in the lower right part of the screen. Then, the brake is released, and the message "BRAKE OPERATION" (highlighted in green) indicated on the switch ([7] shown in the figure below) is changed to the message "BRAKE RELEASED" (highlighted in yellow).








ROBOT (1) BRAKE RELEASE screen

After the procedures shown above are completed, the brake is released. Touch the "BRAKE OPERATION" switch ([7] shown in the figure above) in the lower right part of the screen again, while touching the "AUX OPERATE" switch ([6] shown in the figure below). Then, the brake is actuated (locked), and the message "BRAKE RELEASED" (highlighted in yellow) indicated on the switch in the lower right part of the screen is changed to the message "BRAKE APPLIED" (highlighted in green).

2. Using compulsory release switch on PCB PI-50-01 in robot controller

This method enables compulsory release of the holding brake regardless of the display on the teaching menu screen. Use it to release the holding brake in case of emergency, such as failure in operation of the CPU.

Supply power to the robot controller, and turn on the power switch. When the ready switch is OFF, or when the machine is in "SERVO OFF" status, the holding brakes for Z1 and Z2 can be individually released, while the SW1 or SW2 is being pressed on the PI-50-01 PCB.








When power is supplied with the side door of the robot controller opened, power voltage is supplied to the robot controller. DO NOT touch the power terminals. Otherwise, you may suffer electric shock.


3.5 Robot coordinate system

Coordinate system of SR565Y θ -Z



3.6 Ready circuit


Ready circuit in robot controller RC5500-S



3.7 Precautions

Precautions for withstand voltage test

Because the robot controller RC5500 Series incorporates the indirect lightning stroke surge protector, the surge protector is tripped during withstand voltage (700 VAC or more) test against the controller, leading to impossibility of precise measurement. Before conducting withstand voltage test for the RC5500 series, be sure to disconnect the wire from the ET terminal on the TB4 terminal block inside the robot controller. Always close the side door before withstand voltage test. Do not forget to connect the wire to the ET terminal after elapse of at least 10 minutes from completion of the test.



Interval view of controller left side

3.8 Guarantee period and coverage

1) Guaranteed coverage

If any malfunction occurs to our products during the guaranteed period due to faults in materials or workmanship responsible for us, we will repair them free of charge.

2) Guarantee period

The shortest period among the periods shown below will be applied as the guaranteed period.

- i. Within one year from date of shipment
- ii. Within 2500 operation hours from date of shipment

3) Limitations

Note that faults shown below are out of our guarantee.

- i. Faults caused by inappropriate storage or handling by customers
- ii. Faults caused by unauthorized modifications to products by customers
- iii. Faults caused by external factors such as fires and abnormal voltage, or acts of God such as earthquakes, thunderbolts, typhoons, and floods

4) Items out of guarantee

Products of which guarantee periods were ended and faults described in the 3) above are out of our guarantee. All the required repairs to them will be charged. Investigation of causes of faults made upon customers' request will be also charged.

Expiration of charged repair period after discontinuance of production
 Charged repair period will be ended seven years after the discontinuance of production.

[Revision record]

May 2010, first edition, RC5500-S Ver 1.00 RC5500-S0001

Dec 2016, Revision edition, RC5500-S Ver 1.01 RC5500-S0002

Feb 2018, Revision edition, RC5500-S Ver 1.02 RC5500-S0003

ADVANCED THREAD TIGHTENING ROBOT NITOMAN RC5500-S THREAD TIGHTENING ROBOT CONTROLLER

USER'S MANUAL

Ver1.02

NITTO SEIKO CO., LTD.

http://www.nittoseiko.co.jp/

• For improvement in performance, specifications may be modified without notice.